



J

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
Запасные части - 备件




①	n	on o n	
	B		JP47285
			JP47286
	?	?	JP45786
	?		JP45787
②			JP48871
③	c		JP43713
④	n d c	v c d	JP42798
⑤	c	o	JP47287
⑥	B		JP44861
⑦	n	on o	JP47304
⑧	v	L v con o	
	L n	c	JP43712
	L n	c	JP48227
⑨	n	n	JP43710
⑩	A	c n An o	JP43709
⑪			
	B		JP46754
	B		JP48684
			JP45778
			JP45779
	?		JP45780
	?		JP48826
	?		JP48827
⑫	n	c conn c o	JP43705
⑬		o n v	JP46813
⑭	c		JP43706
⑮	o		JP46812
⑯	B	B	JP43714
⑰	c		JP47966



① Leitung	Cable	
10/4, 15/4, 25/4		JP43717
1010/4 BWI, 4 m		JP43721
1010/4 BWI, 15 m		JP43722
② Stator + Gehäuse	Stator + Housing	
10/4, 15/4, 25/4		JP43722
1010/4 BWI		JP43722
③ Rotorwelle	Rotor shaft	
10/4, 15/4, 25/4		JP43791
1010/4 BWI		JP43801
④ Motorabdichtung	Motor seals	JP43806
⑤ Laufradbefestigung	Impeller fixation	
10/4, 15/4, 25/4		JP43807
1010/4 BWI		JP43807
⑥ Lagersatz	Bearing set	JP43772
⑦ Lagerschild	Bearing housing	JP43772
⑧ Dichtungssatz	Seal set	JP43807
⑨ Laufrad	Impeller	

JP43793	10/4
JP43794	15/4
JP43795	25/4



UC 25/2 - 35/2

①	L	n		JP43717
②				
